












**19 SPARE PARTS**

**19.1 Car**

Name. Car details	Order Nr	Picture
31:0 Position Button / Call button in car RT 42	101303	
Floor indicator	101426	
Safeline 1000 emergency alarm phone	101232	
Voice synthesiser VA03-24	101503	
Stop on car roof 41:	101350	
Speaker HT40 for voice synthesiser	101506	
Stop on car roof 41:	100740	
Stop on car roof 41:	100743	






Name. Car details	Order Nr	Picture
Stop C side on car roof 41:C	704885	
Rotary switch 42:DS	100764	
Contact nc 42:DS	100745	
Extra contact nc42:DS	100740	
PLC for car doors (only lifts with 1 entrances) Need to now lift number.84	101495	
PLC for car doors (only lifts with 2 entrances) Need to now lift number.84	101464	
Micro switch66:AO66:AC 66:CO 66:CC	101580	
Micro switch83:A 83:C Pulse	101581	
LIMIT SWITCH (with click) 63 and 66	100752	

Name. Car details	Order Nr	Picture
LIMIT SWITCH (without click) 52:B and 52:D	101771	
LIMIT SWITCH51	100755	
Door zone transmitter (Cigar type) 30	101610	
Car door machineM85 A and C side	700427	
Car door contact Female87:C 87:A	100575	
Car door contact Male87:C 87:A	100574	
Slide shoe	700234	
Electric key in car	101777	
Electric key in car	101778	

Name. Car details	Order Nr	Picture
Gas spring (Need to now lifting height or Motala lift number).	101711	
Slow speed PC board (car doors)	704992	
Power supply PC board (car doors)	705204	
Switch for running car doors	101380	

## 19.2 Control panel



Name. Control panel details	Order Nr	Picture
537 591:O 591:S 523 67:AO 67:AC 67:CO 67:CC CONTACTORS	101308	
CONTACTOR464 464:B	101060	
Help contact464 464:B	100735	
CONTACTOR 530	101268	
CONTACTOR (gold plated contacts) 521:N 521:U 530:H 530:L Not used any more. Please ask for an instruction how to disconnect them if you find them defective.	101371	
SOCKETS for relays 521:N 521:U 530:H 530:L Not used any more. Please ask for an instruction how to disconnect them if you find them defective.		
Input relay 444 444:A 463 469	100771	
CONTACTOR 201:1 201:2 209	101101	

Name. Control panel details	Order Nr	Picture
Help contact 201:1 201:2 209	100735	
PLC Main system (TSXmicro) Need to now lift number. PL7-Micro include the IO modul	101149	
IO modul PLC (TSXmicro) PL7-Micro	101430	
Safety relays low pit and car depress board 408:A/481:A	101524	
Key for control panel door (PL7 micro before July 2005) Control panel cabinet	Please ask for	
Key for control panel door after July 2005 Control panel cabinet	Please ask for	
Emergency lowering tool. Need to now Motala lift number (Control panel cabinet)	Please ask for	
Emergency door opening tool.	101427	
Safety screw driver door (kone shield)	100658	

Name. Control panel details	Order Nr	Picture
Yaskawa frequency drive	101565	
Main power supply PC board	704478	
Alarm and battery charge PC board	101172	
Battery 12V	100633	
Main switch 220	101107	
Filter	101085	
Filter (brake) PC board	704477	
Brake Resistor	705206	
Phase controller 232	101110	

Name. Control panel details	Order Nr	Picture
Push button switch 270 and 273	101108	
Automat Fuse 281	101105	
Automat Fuse 290	101103	
Automat Fuse 286	101104	
Switch 226:1 and 226:2	101229	





19.3 Machine room in top

Name. Top machine room details	Order Nr	Picture
Rubber for coupling. You ned 2pc	101466	
Safety gear Key	100282	
Sprocket A and C-side Key	100283	
Gearbox Key	100285	
Sprocket A and C-side	700266	
Sprocket house A and C-side	700229	
Ball bearing in sprocket house A and C-side		
Overload unit	100407	
Downwards Block Electro Magnet73	100788	
LIMIT SWITCH (with click) 126	100752	

Name. Top machine room details	Order Nr	Picture
LIMIT SWITCH (without click)127 and 155	100754	
Safety gear	710427	
Stop (safety gear)	700248	
Termostat (only on Bonfiligioli Motor M01)	101679	
Fan (only on Bonfiligioli Motor M01”	101678	
Key for cabinett door machine room (only MC3000 from year 2005) Motor Cabinett.	101728	
Lock for cabinett door	100384	

19.4 Shaft

Name. Shaft details	Order Nr	Picture
31:0 Position Button / Call button in car RT 42 ( in car, need to now layout).	101303	
Stops in pit 112:A/112:C	704901	
Locker wire (need to now total length)	100939	
LIMIT SWITCH (without click) 155	100754	
Door contact 120:/121:	101182	
Door lock Right hanged swing door122	101187	
Door lock Left hanged swing door122	101188	
DC MOTOR DOOR swing door129:0-7	100849	

Name. Shaft details	Order Nr	Picture
Cog wheel DC motor swing door	700071	
Damper swingdoor machine	101478	
Swingdoor machine	704843	
Door closer swingdoor (if fitted) Swing door/Frame	101119	
Grease Superlube Tube for lubricate inside guides	100401	
Cargoflow lubricate spray	101588	
Plastic cover for emergency opening hole	101429	